

Installation & Setup Guide Planersoftware 3.0 Plug-In

GEALAN's Planersoftware 3.0 Revit Plug-In is a powerful extension that enables architects and planners to seamlessly integrate Planersoftware 3.0 into their Revit projects. With this Plug-In solution, users can plan and configure window and door elements in their Revit projects with maximum efficiency and design freedom. It is **free of charge** for architects, planners and BIM users.

1. Perform Installation

- Download the installation file for the Planersoftware 3.0 Revit Plug-In and install it on your system

2. Register on the GEALAN homepage

- Register on the official GEALAN homepage at: <https://www.gealan.de/en/account/registration/>
- Register on the website if you do not already have an account. Otherwise, log in with your credentials

3. Call up the Planersoftware 3.0 once in the browser

- After successful registration or login to the GEALAN homepage, you **need to** call up the Planersoftware 3.0 once in your browser: <https://www.gealan.de/en/architects-designers/planersoftware/>
- Click on "ACCESS TO PLANERSOFTWARE 3.0" and follow the instructions until you are in Planersoftware 3.0

4. Sign in to the Revit Plug-In

- Open Revit and go to the Planersoftware 3.0 Plug-In under the Add-Ins
- Under the settings, log in with your registered E-Mail address and the password you have created on the GEALAN homepage

5. Using the Planersoftware 3.0 Plug-In

- After successfully logging in to Revit, you can now use the Planersoftware 3.0 Plug-In to its full extent. Click on "Project" or "New Element" in the menu bar to access the wide range of functions and configure window and door elements according to your requirements

With these simple steps, the Revit Planersoftware 3.0 Revit Plug-In is at your disposal to optimize your BIM design and create high-quality models of windows and doors.

Contact

If you have any questions, please feel free to contact our BIM experts at

bim@gealan.de

Tutorialvideos



To the Tutorials